



RT-4030 User Manual

Product Overview

This manual provides important information for the safe use, care, and maintenance of the Stronger Tool Low-Profile Tool Tray (RT-4030). The RT-4030 is a compact, heavy-duty rolling tray designed to keep tools, fasteners, and workshop essentials within easy reach while working at floor level.

Constructed from durable powder-coated steel, the low-profile design allows the tray to slide easily under vehicles, workbenches, shelves, and tool cabinets. Smooth-rolling castor wheels provide effortless mobility, making it ideal for automotive work, garages, workshops, and home DIY use.

The RT-4030 is delivered fully assembled and ready for immediate use.

Key Features:

- **Low-profile design** for easy access in tight and under-vehicle spaces
- **Heavy-duty steel construction** with powder-coated finish for durability
- **Smooth-rolling castor wheels** for easy movement on workshop floors
- **Compact footprint** for convenient storage when not in use
- Ideal for **garages, workshops, automotive work, and home DIY**

Package Contents

Part No	Item	Quantity	Description
1	Instruction Manual + Warranty Information	1	This instruction and product warranty
2	Low profile tool tray	1	RT-4030 product

Safety Instructions

Before using the Low-Profile Tool Tray, read and follow all safety instructions below to reduce the risk of injury or damage.

General Safety

1. Use the product **only for its intended purpose** - storing and moving tools, fasteners, and workshop accessories.
2. **Indoor use only.** Do not expose the tray to rain, standing water, or outdoor environments.
3. Always use the tray on a **flat, stable surface** to prevent unintended movement.
4. Keep **hands, feet, and loose clothing clear of the wheels** while the tray is in motion.
5. Do not allow **children to play with or ride on** the tray.
6. Never stand, sit, or climb on the tray. It is not designed to support body weight.

Loading & Use

1. Do not exceed the **maximum recommended load capacity**. Overloading may cause instability or wheel failure.
2. Distribute tools and items **evenly across the tray** to maintain balance.

- 3. Avoid sudden pushes, pulls, or impacts when the tray is loaded.
- 4. Do not use the tray as a step, stool, or support platform.
- 5. When working under vehicles, ensure the tray is positioned **clear of lifting equipment and jack points**.

Wheels & Movement

- 1. Move the tray slowly and carefully, especially on uneven or smooth surfaces.
- 2. Inspect wheels regularly and remove debris such as metal shavings, dirt, or hair to ensure smooth operation.
- 3. Do not roll the tray over cables, hoses, or sharp objects that may damage the wheels.

Maintenance & Inspection

- 1. Inspect the tray periodically for signs of damage, loose components, or excessive wear.
- 2. Discontinue use if the tray becomes unstable or damaged and contact customer support if necessary.
- 3. Do not modify or alter the product. Unauthorized modifications may compromise safety and void warranty.

Safety Limits

Specification	Limit
Maximum Load Capacity (total)	15 kg
Intended Use	Tool storage and indoor transport only
Surface Type	Flat, hard indoor surfaces

Important:

Do not exceed the maximum load capacity of ⚠️ **15 kg**. Overloading may cause instability, wheel damage, or injury. Always distribute weight evenly across the tray and avoid sudden movements when loaded.

Maintenance and Care

Proper care will help maintain the performance and appearance of your rolling tray.

- Clean regularly using a soft, damp cloth to remove dust, grease, and workshop debris.
- For stubborn dirt or oil, use a mild detergent diluted in water.
- Avoid abrasive cleaners, solvents, or harsh chemicals, as these may damage the powder-coated finish.
- Dry all surfaces thoroughly after cleaning to prevent moisture build-up and corrosion.
- Periodically inspect the tray and wheels for signs of damage or excessive wear.
- Remove debris such as metal shavings, dirt, or hair from the wheels to maintain smooth rolling performance.
- If surface scratches occur during normal use, they are cosmetic only. Touch-up paint or a rust-inhibiting spray may be applied if desired.

Storage Recommendations

- Store the rolling tray in a dry, indoor environment away from moisture and direct exposure to water.
- When not in use for extended periods, remove heavy tools to reduce long-term stress on the tray and wheels.
- Avoid storing the tray near corrosive substances such as chemicals, solvents, fertilisers, or salt.
- Do not stack heavy items on top of the tray during storage.

- Store on a level surface to maintain wheel alignment and stability.

Quality Check (Before Use)

- Confirm the tray sits flat and stable on all wheels.
- Ensure wheels roll smoothly without obstruction.
- Verify there are no visible cracks, sharp edges, or damage.

Troubleshooting

Issue	Possible Cause	Solution
Tray does not roll smoothly	Debris in wheels	Clean wheels and remove debris
Tray feels unstable	Uneven surface or overload	Move to a flat surface and reduce load
Unusual noise when moving	Wheel wear or obstruction	Inspect wheels and clean or replace if necessary

Customer Support

Email: au-cs@strongertool.com

Website: <https://au.strongertool.com> → Message us section

Warranty Coverage

Your Stronger Tool compact tool cart is covered by the following warranty:

- **5-Year Automatic Warranty**
Covers defects in materials and workmanship under normal domestic use from the date of purchase. No registration required.
- **10-Year Extended Warranty (with Registration)**
Customers who register their product within 30 days of purchase are eligible for an extended warranty of up to 10 years from the original purchase date.
- **Wheels & Castors – 12 Months Only**
Wheels, castors, and moving wheel components are covered for 12 months from the date of purchase only, due to normal wear and tear associated with use.

Repair or replacement will be provided at Stronger Tool's discretion.

Surface rust, cosmetic wear, and damage caused by misuse or neglect are excluded.

Conditions of Warranty

- The product must be operated and maintained in accordance with the instructions supplied.
- Any repair or replacement does not extend the original warranty period.
- Use of non-genuine Stronger Tool parts will void this warranty.
- Warranty applies to domestic use only and does not apply to commercial or industrial applications.

Product Registration (10-Year Warranty)

To qualify for the extended 10-year warranty, customers must:

- Register the product within 30 days of purchase
- Provide valid proof of purchase
- Complete the registration accurately

Products not registered within this period will remain covered under the 5-year automatic warranty.

Warranty Claims – Australia

The warranty for Australia is provided by:

STRONGER TOOL Australia

Address: 10 Drovers Way, Lindfield, NSW 2070, Australia

Phone: +61 (0) 492 969 739

Email: au-cs@strongertool.com

To submit a warranty claim, please contact our customer support team with:

- Proof of purchase
- Product details
- Description of the issue (photos may be requested)

Stronger Tool will bear reasonable, direct expenses associated with valid warranty claims, subject to assessment.

Australian Consumer Law

This warranty is provided in addition to your rights under the Australian Consumer Law (ACL).

Our goods come with guarantees that cannot be excluded under the ACL. You are entitled to:

- A replacement or refund for a major failure
 - Repair or replacement if the goods fail to be of acceptable quality and the failure does not amount to a major failure
-

What Is Not Covered

This warranty does not cover:

- Wheels and castors beyond the initial 12-month period
- Removal or re-installation costs
- Transit damage not reported at the time of delivery
- Lack of maintenance, abuse, neglect, misuse, or accidental damage
- Improper installation or unauthorised modification
- Scratches, dents, corrosion, or discoloration caused by:
 - Heat
 - Abrasive or chemical cleaners
 - Weather, insects, grease, or corrosive substances
- Commercial or industrial use
- Unauthorised repairs during the warranty period